


A-JB6 Adjust-A-Body® with Hanger Bolt Tensioner Cable For 1/8" Or 3/16" Cable. Use F-4 Ferrule for 1/8" and F-6 Ferrule for 3/16"



Adjust-A-Body® with Hanger Bolt Tensioner
This tensioner screws right into your wooden end post. There is no need for special mounting hardware.



TYPE AND SWAGING SIZES

CABLE DIA.	POST DIA.	FERRULE DIA.	1/8"	3/16"	1/4"	5/16"	3/8"	1/2"	5/8"	3/4"	1"	DRILL BITS REQUIRED	DRILL BIT REQUIRED
1/8"	A-JB6	F-4	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	1/8"	1/8"
3/16"	A-JB6	F-6	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	3/16"	3/16"
1/4"	A-JB6	F-8	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	5/16"	1/4"	1/4"

*Order from us only. NOTE: If soft wood (Common Redwood), 7/32" drill bit; if hard wood (Common Douglas Fir), 15/64" drill bit.
FERRULE ITEM# are CAF-4, CAF-6 or CAF-8

- This tensioner screws right into your wooden end post. There is no need for special mounting hardware.
- Require Swaging or Purchase cable with pre-swaged ferrule.
- *Order Ferrule separately. NOTE: If soft wood (Common Redwood), 7/32" drill bit; if hard wood (Common Douglas Fir), 15/64" drill bit. Ferrule Item# are CAF-4, CAF-6 or CAF-8